

## **LECTURE NOTES**

**ON**

# **ADVANCED CONSTRUCTION TECHNIQUES AND EQUIPMENT**

**(Session 2023-24)**

*Compiled by*

**Abhijeet Prasad Dash, Lecturer**

Department of Civil Engineering,  
KIIT Polytechnic, Bhubaneswar

# CONTENTS

S.N.	CHAPTER NAME	PAGE NO.
1	Advanced construction materials	1-12
2	Prefabrication	14-25
3	Building services	26-38
4	Questions and answers	39-48
5	Construction equipment	48-61

KIIT – Abhijeet Prasad Dash

**Learning Materials (Th.3)**  
**ADVANCED CONSTRUCTION TECHNIQUES & EQUIPMENT**  
**Semester- 6<sup>th</sup>**  
**KIIT Polytechnic, Bhubaneswar**

**Chapter 1: Advanced construction materials**

**(A) Plastic as Construction Material**

Plastic is a general name given to a wide range of synthetic materials that are based on polymers. The construction industry uses plastic for a wide range of applications because of its versatility, strength-to-weight ratio, durability, corrosion resistance, and so on.

Plastic can be manufactured into forms such as; pipes, cables, coverings, panels, films, sheets and so on; and can be formed or expanded to create low-density materials; and be dissolved in solvents.

Some of these plastics main uses in the construction industry are,

- Cladding panels.
- Cables
- Pipes and gutters.
- Windows and doors.
- Shuttering
- Wall linings
- Floor covering
- Ceiling panels.
- Roof coverings.
- Sinks, basins, baths, and showers.

: The advantages of using plastic in construction are that it is lightweight yet strong which makes it easier to transport and shift around sites. It is also resistant to rot and corrosion and has strong weather ability due to it being capable of achieving tight seals.

: The disadvantages of plastic are that it has a high embodied energy content and a low modulus of elasticity, meaning that it is generally unsuitable for load-bearing applications.

## **PROPERTIES: -**

: Typically, construction professionals select plastic materials based on the following criteria:

1. Durability
2. Cost effectiveness
3. Recycling
4. Energy saving
5. Safety
6. Easy to install

## **Use of Plastics in Different Aspects of the Construction Industry**

### **1.Flooring**

Plastic materials like polyvinyl chloride (PVC) and polyethylene are used to make flooring less prone to wear and tear. It also decreases the sound pollution level and can be cleaned easily.

### **2.Roofing**

To protect the outer surface of the roof from damage, two layers of different plastic materials are required. The upper part is made of colored thermoplastic olefin or vinyl while the lower part consists of polyurethane foam which consumes less energy and keeps the interior of a house cooler.

### **3.Insulation**

Polyurethane spray is frequently used for insulation when constructing green or low energy buildings. Rigid polyurethane foam is known for its high thermal resistance which promotes temperature consistency. Polyurethane foam is also popular because it is lightweight, chemical resistant, and flame retardant. Due to its closed cell nature, polyurethane insulation performs as an air barrier, resulting in significant energy savings.

### **4.Wall**

A structural insulated panel (SIP) is a sandwich of expanded polystyrene amidst two slim layers of oriented strand board. This type of pre-fab, composite wall board can be transferred to the work place easily for a particular task and provide good support to columns and other associated essentials during renovation.

### **5.Pipes**

Commonly made up of polyvinyl chloride (PVC), CPVC, acrylonitrile butadiene styrene (ABS) or polyethylene, plastic pipes are flexible and very light in weight, making them easy to install. All of these plastic materials are also highly chemical and water resistant, making them suitable for many extreme environments.

### **6.Windows**

Polycarbonate is used to manufacture building windows. This plastic material is strong, clear and very light in weight. Polycarbonate windows are considered more burglar-proof than regular glass windows. Two plastics materials, vinyl and fiberglass, are used commonly in the production of window frames. Fiberglass is extremely strong while vinyl is quite durable and also inexpensive.

#### 7. Doors

Some construction projects use doors made from a stiff polyurethane foam core with a fiber reinforced plastic (FRP) coating. The sandwich structure of these doors makes them incredibly strong.

#### **TYPES:-**

##### **PVC:-**

Polyvinyl chloride (PVC), a synthetic resin made from the polymerization of vinyl chloride. Second only to polyethylene among the plastics in production and consumption, PVC is used in an enormous range of domestic and industrial products, from raincoats and shower curtains to window frames and indoor plumbing. A lightweight, rigid plastic in its pure form, it is also manufactured in a flexible “plasticized” form.

##### **RPVC:-**

RPVC means Rigid PolyVinyl Chloride which comes from PVC. Polyvinyl chloride (PVC), also known as vinyl, is a common plastic polymer (a polymer being a large molecule). It comes in two basic forms: flexible and rigid (RPVC). RPVC is used in construction (especially pipes), packaging etc. RPVC Pipes with high impact strength & load bearing capacity!

##### **HDPE:-**

High density polyethylene (HDPE) piping systems have been used for municipal and industrial water applications for over 50 years. Within Building & Construction Division, HDPE pipes are used for ground source geothermal applications, also known as earth energy or geoexchange systems.

##### **FRP:-**

Fibre-reinforced plastic (FRP) (also called fiber-reinforced polymer). FRP bars are used as internal reinforcement for concrete structures. FRP bars, sheets, and strips are used for strengthening of various structures constructed from concrete, masonry, timber, and even steel. Fibre reinforced polymers are used in the construction of special structures requiring electrical neutrality.

##### **GRP:-**

GRP stands for 'Glass Reinforced Plastic' a material made from a polyester resin, which is reinforced by chopped strand mat glass fibres to form a GRP laminate. It is a very popular composite material to use because not only is it very strong but also surprisingly light.

#### **Coloured Plastic Sheets:-**

Plastic film is a thin continuous polymeric material. Thicker plastic material is often called a "sheet". Plastic sheets are generally low cost, easy to manufacture, durable, strong for their weight, electrically and thermally insulative, and resistant to shock, corrosion, chemicals, and water.

## **(B) FIBER AS A CONSTRUCTION MATERIAL**

- Fiber or fibers is a class of material which are having continuous filaments or having discrete elongated pieces similar to the length of thread.
- Fibers are very important in the biology of plants and animals for holding tissue together. They are often used in the manufacture of other materials.
- Fibers can be spun into filaments or string or rope which can be used as a component of composite material or matted into sheets so as to make the products like paper or felt.
- Fibers are inorganic or organic, natural or synthetic. Synthetic fibers can be produced very cheaply and in large amounts as compared to natural fibers. Rayon and nylon are organic synthetic fibers.
- Burlap is a coarse jute or hemp which is a natural fiber. Hessian is a jute fabric. Silk and cotton are produced from natural fibers.
- Glass wool, lead wool and asbestos are mineral fibers of which glass wool and lead wool are synthetic fibers.
- Steel fiber, carbon fiber and glass fiber are the new and recent trends used in the construction work.

### **General Uses of Fibers**

- Fibers are used for packing and making fabrics and felts.
- Glass wool made of very fine fibers of glass is used for making acid-proof and fire-proof fabrics.
- Glass wool is also used as a packing material for heat, sound and electric insulation. It is commonly used in a solar water system.
- Lead wool prepared from fine fibers of lead is used in water pipe joints to stop leakage of water. Natural jute fibers are extensively used in plumbing work to stop leakage of water.

### **Types of Fibers :**

There are mainly three types of fibers which are commonly used as a construction materials.

#### **1. Steel fiber**

Steel fiber are made from the cold drawn steel wire with low content of carbon or stainless steel wire. They are manufactured in various types such as hooked steel fibers, undulated or

flat steel fibers according to the need required in the construction project. These fibers are used in the construction for concrete reinforcement. Steel fiber reinforced concrete is less expensive than hand tied re-bar shape, dimensions and length of the fiber are more important because it increases the tensile strength of the concrete.

Steel fibers can only be used on surfaces so as to avoid corrosion and rust stains. Fiber-reinforced normal concrete is mostly used for on-ground floors and pavements and also used for the construction parts such as beams, pillars, foundation etc.

### **Properties of Steel Fibers**

- It increases the tensile strength of concrete.
- It is more tough and hard.
- It avoids corrosion and rust stains.
- They are more elastic in nature.
- Steel fibers are available with standards as ASTM 820/96, ASTM C 1116/95 and DIN 1045.
- It has a tensile strength of 1.100 N/mm<sup>2</sup>.
- They are available in the shapes like flat, hooked and undulated.

### **Applications of Steel Fibers on Field**

- Steel fibers are highly used in tunnel lining work.
- It is mostly used in the construction of airport runways and highway pavements.
- Most commonly used in precast concrete so as to increase the tensile strength.
- They are used in shotcrete.
- Used in the construction of parking.
- It is used in anti-seismic buildings.

## **2. Carbon fibers**

Carbon fiber is a material consisting of extremely thin fibers about 0.005 mm to 0.010 mm in diameter and mostly composed of carbon atoms. Carbon fiber is alternately called graphite fiber. The carbon atoms are bonded together in microscopic crystals which are more or less aligned parallel to the long axis of the fiber. The crystal alignment makes size of fiber more strong. Number of carbon fibers are twisted together so as to form a Yarn which can be used as it exist or woven into a fabric. It can be combined with a plastic resin and wound or moulded to form composite materials like carbon fiber reinforced plastic to provide a high strength to weight ratio of the materials. The atomic structure of carbon fiber is similar to that of graphite consisting of sheets of carbon atoms arranged in a regular hexagonal pattern. Carbon fibers shows the number of properties very close to the properties of asbestos. Each carbon filament thread

is a bundle of many thousand carbon filaments. A single such filament is a thin tube with a diameter of 5-8  $\mu\text{m}$  (i.e. 5-8 micrometres) and consists of almost exclusively of carbon.

### **Properties of Carbon Fibers**

- It has a high tensile strength, low weight and low thermal expansion.
- They are rigid materials which are resistant to stretching and compression.
- It is chemically inert or unreactive materials.
- They are resistant to corrosion.
- Fibers contained about 85% carbon has excellent flexural strength.

### **Application of Carbon Fibers**

- Carbon fiber is mostly used to reinforce composite material.
- Reinforced Carbon-Carbon (RCC) consists of carbon fiber-reinforced graphite and is used structurally in high temperature applications.
- It increases the tensile as well as compressive strength of concrete.
- Due to high tensile strength, low weight and low thermal expansion it makes the carbon fiber very popular in aerospace, military and motorsports along with other competition sports.
- Carbon fiber is extensively used in the bicycle industry, especially for high-performance racing bikes.
- It is also used in some tennis rackets.
- It is now being used in musical instruments for its weather resilience and ability to recreate the tone of guitars.

## **3. Glass fibers**

It is also called as fiber glass. Glass fiber is the material made from extremely fine fibers of glass. It was invented in 1938 by Russell Games Slayter. In 1893, Edward Drummond Libbey exhibited a dress at the World's Calumbian Exposition incorporating glass fibers with the diameter and texture of silk fibers. This was first worn by the well known and popular stage actress of the time Georgia Cayvan. There are two main types of glass fiber manufacture and two main types of glass fiber product. First fiber is made either from a direct melt process or a marble remelt process. Both start with the raw materials in solid form. It is almost always made of platinum alloyed with rhodium for better durability. Platinum is used because the glass melt has a natural affinity for wetting it. The fresh and thin fibers are more strong because the thinner fibers are more ductile.

### **Properties of Glass Fibers**

- It has high ratio of surface area to weight.
- They have good thermal insulation.
- It has a good tensile strength but has no strength against compression.
- Compressive strength is weak but can be increased by reinforcing it with plastic.



- When the glass fiber is reinforced with plastic, then reinforced material can resist both compressive and tensile forces as well.
- It is resistant to chemical attack. However, if its surface area is increased, then it makes them more susceptible to chemical attack.
- They are corrosion resistant.

### **Application of Glass Fibers**

- Corrugated fiber glass panels are widely used for outdoor canopy or greenhouse construction.
- It is used as a reinforcing agent for many polymer products like FRP and GRP which uses tubs, pipes for drinking water and 'sewers, office plant containers and flat roof systems etc.
- It is reinforced with plastic material so as to increase tensile strength.
- Uses of regular fiber glass are mats, insulation, reinforcement sound absorption, heat resistance fabrics, corrosion resistant fabrics and high strength fabrics.
- Glass fiber reinforced plastics are used in the house building market for the production of roofing laminate, door surrounds, over-door canopies, window canopies and dormers, chimneys, coping system, heads with keystone and sill etc.
- The reinforced glass fiber with polymer and plastic is commonly used in fire water systems, cooling water systems, drinking water systems, sewage systems, waste water systems, gas system etc.

### **(B) ARTIFICIAL TIMBER**

Reduction of moisture content along with improving some qualities before the use of woods is called seasoning of timber. By seasoning, generally, the moisture is reduced to about 15% where new cut woods bear about 50%.

#### **Reasons for Seasoning**

Seasoning of timber is done to fulfill some specific requirement. Followings are the reasons to perform timber seasoning.

- 1.To change and improve the properties of wood.
- 2.To make a correct percentage of shrinking of woods.
- 3.To make a confident use of woods.
- 4.To reduce the adverse behaviour of woods.


## Methods of Seasoning of Timber

There are mainly two methods of seasoning of timber. These are:

A) Natural Seasoning

B) Artificial Seasoning

Following tree diagram can be used to illustrate all the methods of timber seasoning.



### Natural Seasoning

Seasoning of woods or timbers using natural elements is called natural seasoning. eg. water and air seasoning.

#### a. Water seasoning

Removal of wood sap immersing logs into water flow is called water seasoning. It is carried out on the banks of the river while thicker ends are kept towards upstream. After that, the logs are allowed to dry. Disadvantage: It is time consuming such as 2 to 4 weeks generally.

#### b. Air seasoning

Exposing the woods to air for seasoning. At first, a platform is required that is built on the ground at 300mm height above the ground.

Secondly, the arrangement of woods in layers. Air circulation is maintained between logs because it helps to reduce the moisture which is important for seasoning. The environment for this need to maintain some conditions. A clean, shady, dry, cool place is preferred. Sometimes logs are coated by the impermeable substance to reduce extreme moisture. To improve the quality oil coating,

thick paint coating is maintained. To prevent fungal infection logs are treated with petrol or gasoline.

**Advantage:**

- Good quality of seasoned wood.
- A large amount is convenient in this process.
- Well-seasoned timber is formed.

**Disadvantage:**

- It's a slow process.

**Artificial Seasoning**

**a. Seasoning by Boiling**

Seasoning by boiling wood logs in hot water is called seasoning by boiling. Drying is done after proper boiling. For a large amount of wood, it is done in an enclosed place where hot steam is passed.

**Advantages**

- It takes a short amount of time. Generally, 3-4 hours is good enough. Develops the strength and elasticity.

**Disadvantages**

- It is serviceable basically for a small quantity of wood, not convenient for a large amount. The cost is high.

**b. Chemical seasoning**

Reduction of moisture using salt solution is called chemical seasoning. After the absorption of water by the solution logs are let to dry.

**Advantage**

- It increases the strength of the timber.
- It is less time-consuming.

**Disadvantage**

- Chemical reagents can sometimes reduce strength.
- It can cause a problem in gluing or finishing or corrosion while using.

**c. Kiln seasoning**

Seasoning of wood by using a large chamber or oven where there is a good process for the circulation of hot air.

**Advantage**

Most effective and economic seasoning.

Kiln seasoning can be done by 2 processes such as: -

- **Progressive kiln Seasoning:** Wood log is entered through the kiln and the temperature and humidity differentials are maintained through the length of the kiln to maintain proper drying.
- **Compartmental Seasoning:** It's maintained by enclosed container or buildings. Advantage: It accelerates the process because external energy is used.

#### **d. Electrical seasoning**

Dry wood is non-conductor of electricity while green timber is a conductor, so, can pass alternating current. Thus, in this method alternating current is used for the resistance of timber against electricity is measured at every interval of time. When the required resistance is reached seasoning, process is stopped because resistance of timber increases by reducing moisture content in it. It is also called as rapid seasoning and it is uneconomical.

#### **(C) Miscellaneous Materials.**

A category of asbestos-containing building material comprised mostly of nonfriable asbestos products and materials, such as ceiling tiles, floor tiles, roofing felt, transit pipes and panels, exterior siding, fabrics, and sheetrock systems.

- **Acoustics Material**

When the sound intensity is more, then it gives the great trouble or nuisance to the particular area like auditorium, cinema hall, studio, recreation centre, entertainment hall, college reading hall. Hence it is very important to make that area or room to be sound proof by using a suitable material called as 'Acoustic material'. It is measured in decibels (db).

##### **Properties of Acoustic Material**

- Sound energy is captured and adsorbed.
- It has a low reflection and high absorption of sound.
- Higher density improves the sound absorption efficiency at lower frequencies.
- Higher density material help to maintain a low flammability performance. Hence acoustic material should have higher density.
- It controls the sound and noise levels from machinery and other sources for environmental amelioration and regulatory compliance.
- Acoustic material reduces the energy of sound waves as they pass through.
- It suppresses echoes, reverberation, resonance and reflection.

##### **Uses of Acoustic Material**

- Acoustic materials can be used for noise reduction and noise absorption. It makes the sound more audible which is clear to listen without any disturbances.
- 2. It suppresses echoes, reverberation, reflection and resonance.
- Important specifications for noise reduction and noise absorption products include noise attenuation and noise reduction coefficient.
- 4. A vinyl acoustic barrier blocks controls airborne noise (street traffic, voices, music) from passing through a wall ceiling or floor.

- 5. Acoustic foam and acoustic ceiling tiles absorb sound so as to minimize echo and reverberation within a room.
- 6. Sound proof doors and windows are designed to reduce the transmission of sound.
- A sound proof wall (treated by a accurate material) can incorporate sound proofing and acoustic materials to meet desired sound transmission class (STC) values.

### Wall cladding



Wall cladding is a type of decorative covering intended to make a wall look like it is made of a different sort of material than it actually is. Some of the most common examples are on the outside of buildings, but cladding can also be an artistic element in interior decorating.

The most common types of cladding are Stone Cladding, Brick Cladding, Timber Cladding, Metal Cladding, Concrete Cladding, Glass Cladding.

### Plasterboard



Plasterboard is a panel made of calcium sulphate dihydrate (gypsum) usually pressed between a facer and a backer. It is used to make interior walls and ceilings. This 'Drywall' construction became popular as a quicker alternative to traditional lath application.

## Microsilica



Micro silica or silica fume is an excellent admixture for concrete as it leads to better engineering properties. It reduces thermal cracking, improves durability, and increases strength. Silica fume concrete has a number of construction applications.

## Artificial Sand



Artificial sand, also called crushed sand or mechanical sand, refers to rocks, mine tailings or industrial waste granules with a particle size of less than 4.75 mm, which are processed by mechanical crushing and sieving, but does not include soft and weathered granules.

## Bonding Agents



Bonding agents are natural, compounded or synthetic materials used to enhance the joining of individual members of a structure without employing mechanical fasteners. The most commonly used types of bonding agents are generally made from natural rubber, synthetic rubber or from any

other organic polymers. The polymers include polyvinyl chloride, polyvinyl acetate etc. With the addition of bonding agent in repair mortar or concrete, the reduced water-cement ratio can be adopted for the same workability, thereby reducing drying shrinkage.

### **Adhesive**



Construction adhesive is a general-purpose adhesive used for attaching drywall, tile, moulding, and fixtures to walls, ceilings, and floors. It is most commonly available in tubes intended for use.

## Earthquake Resistant Construction

### 3.1 Building Configuration

Building configuration plays a vital role in how a structure responds to seismic forces. A well-configured building can effectively resist earthquake forces, while a poorly configured one is prone to severe damage or collapse.

#### Key aspects of building configuration:

- **Simplicity and Symmetry:** Simple, symmetrical shapes perform better under seismic loads. Buildings with complex geometries or asymmetry experience uneven stress distribution, leading to potential weak points.
- **Regularity:** Regularity in plan and elevation is crucial. Buildings should have uniform distribution of mass, stiffness, and strength. Avoid sudden changes in these properties.
- **Compactness:** Compact shapes minimize torsional effects. Torsion occurs when the center of mass and the center of rigidity do not coincide, causing the building to twist during an earthquake.
- **Separation of Parts:** If a building has different structural systems or varying heights, consider separating them with seismic joints. This prevents pounding (impact) between adjacent parts during an earthquake.

#### Examples of good and bad configurations:

- **Good:** A rectangular building with uniform height and evenly spaced columns.
- **Bad:** An L-shaped building, a building with a soft story (a story with significantly less stiffness than the stories above), or a building with a large overhang.


### 3.2 Lateral Load Resisting Structures

Lateral loads, such as those caused by earthquakes, exert horizontal forces on a building. Lateral load-resisting systems are specifically designed to withstand these forces and transfer them safely to the ground.

#### Common types of lateral load-resisting systems:

- **Shear Walls:** Shear walls are vertical elements designed to resist lateral forces in their plane. They are typically constructed of reinforced concrete or masonry.

#### Shear Wall



- 
- **Braced Frames:** Braced frames use diagonal members to create a truss-like system that resists lateral loads through axial tension and compression in the bracing elements.



- **Moment-Resisting Frames:** Moment-resisting frames rely on the flexural capacity of beams and columns to resist lateral loads. The connections between beams and columns are designed to transfer bending moments.
- **Dual Systems:** Dual systems combine shear walls or braced frames with moment-resisting frames to provide enhanced lateral load resistance.

#### Considerations for choosing a lateral load-resisting system:

- **Building height and occupancy:** Taller buildings and buildings with high occupancy require more robust systems.
- **Architectural requirements:** The chosen system should be compatible with the architectural design of the building.
- **Cost:** The cost of different systems can vary significantly.

### 3.3 Building Characteristics

Several building characteristics influence its seismic performance. Understanding these characteristics is crucial for designing earthquake-resistant structures.

#### Key building characteristics:

- **Stiffness:** Stiffness refers to a building's resistance to deformation under load. Higher stiffness generally reduces displacement during an earthquake but can also increase the forces experienced by the building.
- **Strength:** Strength is the building's ability to resist forces without failure. Adequate strength is essential to prevent collapse.
- **Ductility:** Ductility is the ability of a building to deform significantly beyond its elastic limit without losing its load-carrying capacity. Ductile structures can absorb energy during an earthquake, reducing the forces transmitted to the building.
- **Mass:** Mass is the amount of matter in a building. Higher mass generally results in higher seismic forces.
- **Damping:** Damping is the dissipation of energy within a structure. Higher damping reduces the amplitude of vibrations during an earthquake.

### 3.4 Effect of Structural Irregularities

Structural irregularities can significantly amplify the seismic forces acting on a building and lead to localized failures. It's important to identify and address irregularities in the design phase.

#### Types of Structural Irregularities:

- **Vertical Irregularities:**
  - **Soft Story:** A story that is significantly more flexible than the stories above or below it.
  - **Mass Irregularity:** A story with a mass significantly greater than the stories above or below it.
  - **Geometric Irregularity:** Vertical setbacks or changes in plan area along the height of the building.

- **Plan Irregularities:**

- **Torsional Irregularity:** When the center of mass and center of rigidity do not coincide, leading to twisting under lateral loads.
- **Re-entrant Corners:** Buildings with L-shapes, U-shapes, or other complex plans with re-entrant corners.
- **Diaphragm Discontinuity:** Significant openings or cutouts in floor or roof diaphragms.

**Mitigation Strategies:**

- **Avoid Irregularities:** The best approach is to design regular buildings whenever possible.
- **Strengthening:** Increase the strength and stiffness of weak elements.
- **Seismic Joints:** Separate irregular portions of the building with seismic joints.
- **Detailed Analysis:** Perform a rigorous seismic analysis to account for the effects of irregularities.

### **3.5 Safety Considerations During Additional Construction and Alteration**

Modifying existing buildings can compromise their seismic resistance if not done carefully. It's crucial to assess the existing structure and ensure that the modifications do not create new vulnerabilities.

**Key Safety Considerations:**

- **Assessment of Existing Structure:** Conduct a thorough structural assessment to determine the existing building's strength, stiffness, and condition.
- **Load Path:** Ensure that the load path remains continuous and that the new construction does not disrupt the existing load path.
- **Increased Loads:** Consider the increased loads due to the addition and ensure that the existing structure can support them.
- **Compatibility:** Use materials and construction techniques that are compatible with the existing structure.
- **Connections:** Pay close attention to the connections between the new and existing construction.
- **Temporary Support:** Provide adequate temporary support during construction to prevent collapse.
- **Compliance with Codes:** Ensure that the modifications comply with current building codes and seismic design standards.

### **3.6 Additional Strengthening Measures in Masonry Buildings**

Masonry buildings are particularly vulnerable to earthquake damage due to their brittle nature. Several strengthening measures can improve their seismic performance.

**Common Strengthening Measures:**

- **Corner Reinforcement:** Adding steel reinforcement at the corners of walls to prevent cracking and separation.
- **Lintel Band:** A reinforced concrete or steel band provided at the lintel level to tie the walls together and distribute lateral loads.

- **Sill Band:** A similar band provided at the sill level of windows and openings.
- **Plinth Band:** A band provided at the plinth level to prevent settlement and cracking of the walls.
- **Roof Band:** A band provided at the roof level to tie the walls together and provide support to the roof.
- **Gable Band:** For buildings with gable roofs, a band provided at the gable level to prevent collapse of the gable wall.

These bands help to improve the overall integrity and seismic resistance of masonry buildings by providing continuity and preventing the walls from separating during an earthquake.

## **Retrofitting of Structures**

### **4.1 Seismic Retrofitting of Reinforced Concrete Buildings**

Seismic retrofitting involves upgrading existing reinforced concrete (RC) buildings to improve their resistance to earthquake forces. This is crucial for older buildings that were not designed to modern seismic standards.

#### **Reasons for Seismic Retrofitting:**

- **Increased Seismic Knowledge:** Our understanding of earthquakes and their effects on buildings has significantly improved over time.
- **Changes in Building Codes:** Building codes have become more stringent, requiring higher levels of seismic resistance.
- **Deterioration:** Existing buildings may have deteriorated over time, reducing their structural capacity.
- **Change of Use:** A change in the building's occupancy or function may require a higher level of seismic resistance.

#### **The Retrofitting Process:**

1. **Seismic Evaluation:** Assess the building's existing seismic capacity and identify its vulnerabilities.
2. **Design of Retrofit Scheme:** Develop a retrofit scheme that addresses the identified vulnerabilities and improves the building's seismic performance.
3. **Implementation:** Implement the retrofit scheme, which may involve strengthening existing elements, adding new elements, or modifying the building's configuration.

### **4.2 Sources of Weakness in RC Frame Buildings**

Identifying the sources of weakness in RC frame buildings is the first step in developing an effective retrofitting strategy.

#### **Common Weaknesses:**

- **Inadequate Reinforcement:** Insufficient amount or improper detailing of reinforcement in columns, beams, and joints.
- **Weak Column-Beam Joints:** Poorly designed or detailed joints that are unable to transfer forces effectively.
- **Soft Story:** A story with significantly less stiffness than the stories above, often due to large openings or a lack of shear walls.

- **Lack of Ductility:** Brittle concrete or inadequate confinement reinforcement that limits the building's ability to deform without failure.
- **Corrosion of Reinforcement:** Corrosion of steel reinforcement, which reduces its strength and bond with the concrete.
- **Deterioration of Concrete:** Cracking, spalling, or other forms of concrete deterioration that weaken the structure.
- **Pounding Potential:** Insufficient separation between adjacent buildings, leading to pounding during an earthquake.

#### 4.3 Classification of Retrofitting Techniques and Their Uses

Various retrofitting techniques are available, each with its own advantages and disadvantages. The choice of technique depends on the specific characteristics of the building and the desired level of seismic performance.

##### Common Retrofitting Techniques:

- **Strengthening of Columns and Beams:**
  - **Concrete Jacketing:** Enclosing existing columns and beams with a new layer of reinforced concrete.
  - **Steel Jacketing:** Wrapping steel plates around columns and beams to increase their strength and ductility.
  - **Fiber Reinforced Polymer (FRP) Wrapping:** Applying FRP composites to columns and beams to enhance their strength and stiffness.
- **Strengthening of Joints:**
  - **Concrete Overlay:** Adding a layer of reinforced concrete to the joint.
  - **Steel Cages:** Encasing the joint with steel cages to improve its confinement and shear strength.
  - **FRP Wrapping:** Wrapping FRP composites around the joint to enhance its strength and ductility.
- **Addition of Shear Walls:** Adding new shear walls to increase the building's lateral load resistance.
- **Infill Walls:** Filling in existing openings with reinforced masonry or concrete walls.
- **Base Isolation:** Isolating the building from the ground using flexible bearings to reduce the forces transmitted to the structure.
- **Energy Dissipation Devices:** Installing devices that absorb energy during an earthquake, reducing the forces on the building.

**Q. Describe lifts and its types.**

ANS:


An elevator or lift is a hoisting or lowering mechanism, designed to carry passengers or freight, and is equipped with a car and platform that typically moves in fixed guides and serves two or more landings.

Classified as:


1. electric traction type
2. hydraulic type

**1. electric traction type**

- Traction elevators have an elevator car and counterweight attached to opposite ends of hoist ropes.
- The hoist ropes pass over a driving machine that raises and lowers the car.
- Traction elevators run on load-bearing rails in the elevator hoist-way.
- Traction elevators are most often used in mid-rise and high-rise buildings with five or more floors.



**Traction Drum Arrangement**




**Lifting Drum Arrangement**

**2. hydraulic type**

- Hydraulic elevators, on the other hand, are raised by forcing pressurized oil through a valve into a steel cylinder located above ground or underground.
- The pressure forces a piston to rise, lifting the elevator platform and car enclosure mounted on it.
- The car is lowered by opening the valve and allowing the weight of the car to force oil from the cylinder in a controlled manner. When the valve is closed the car is stopped.
- Hydraulic elevators are commonly found in low-rise buildings with two to five floors.

Other types are:

1. Bed Passenger Lift
2. Escalator



3. Freight Lift
4. Lift Bank
5. Passenger Conveyor
6. Passenger Lift
7. Service Lift
8. Vehicle Lift

1. **Bed Passenger Lift** means a lift used for transportation of passenger and bed including stretcher.

2. **Escalator** means an inclined, continuous stairway which is driven by mechanical power and used for raising or lowering passengers
3. **Freight Lift** means a lift mainly intended for the transport of goods, which are generally accompanied by persons handling the goods.
4. **Lift Bank** means a lift system with two or more lift cars serving a zone
5. **Passenger Conveyor** means a continuous walkway which is driven by mechanical power and used for the conveyance of passengers on the same or between different traffic levels.
6. **Passenger Lift** means a lift which is wholly or mainly used to carry persons.
7. **Service Lift** means a lift, used or intended to be used exclusively for carrying goods, having a rated load of not more than 250 kg and a car in which the area of the floor is not more than 1 m and whose height is not more than 1200 mm.
8. **Vehicle Lift** means a lift which is suitably dimensioned and designed for carrying motor vehicles

**Q. Uses of lifts and escalator.**

**ANS:**

**Uses of elevators**

1. Passenger Elevators are designed to move people between different floors of a building, their capacity being related to available floor space.
2. Passenger elevators may be specialized for the service they perform, including: Hospital emergency (Code blue), front and rear entrances, double Decker, and other uses.
3. Express elevators are designed to move people from ground floor to a sky lobby skipping several floors in between at a high speed.
4. Wheelchair, or platform lifts, a specialized type of elevator designed to move a wheelchair 6 ft (1.8 m) or less, often can accommodate just one person in a wheelchair at a time with a maximum load of 1000 lb (455 kg).
5. Freight Elevators are meant to carry heavy loads generally 2300 to 4500 kg. They usually don't comply with fire service requirements and carrying passengers is generally prohibited unless specified.
6. On aircraft carriers, elevators carry aircraft between the flight deck and the hangar deck for operations or repairs. These elevators are designed for much greater capacity than any other elevator.
7. A small freight elevator is often called a dumbwaiter, often used for the moving of small items such as dishes in a 2-story kitchen or books in a multi-story rack assembly. Passengers are never permitted on dumbwaiters.

8. A special type of elevator is the paternoster, a constantly moving chain of boxes, generally used in industrial plants.
9. Grain Elevators are used to elevate grain for storage in large vertical silos

#### For the safe use of lifts

- Maintain all the safety devices operative
- Don't overload lifts
- Don't interfere with lift doors and equipment
- Don't use the lift when there is a fire
- Don't jump inside lift
- Children must be accompanied by adults when using lifts
- Stay clear of lift doors, especially when the lift doors are opening or closing

#### For the safe use of escalators

- Hold handrail and to prevent accident, please don't walk on escalators
- Hold children's hand
- Don't lean over handrail
- Don't play or run on escalators
- Keep your feet away from the skirting or yellow stripes
- Keep Trolleys strollers and wheelchairs off escalators
- Don't play with emergency stop button which is to be used only when under emergency situation.

#### Q. Describe soil and waste water installations in high rise buildings

Ans:

#### Materials used for waste and discharge systems

Material	Application	Jointing
Cast iron	50 mm and above vent and discharge stacks	Lead caulking with molten or fibrous lead; cold compound caulking
Galvanized steel	Waste pipes	BSPT screwed
Copper	Waste pipes and traps	Compression, capillary, silver solder, bronze weld or push-fit ring seal
Lead	Waste pipes and discharge stacks	Soldered or lead welded
ABS	Up to 50 mm waste and vent pipes	Solvent cement and push-fit ring seal
High-density polyethylene	Up to 50 mm waste and ventilating pipes and traps	Push-fit ring seal and compression fittings
Polypropylene	Up to 50 mm waste and ventilating pipes and traps	Push-fit ring seal and compression couplings
Modified PVC	Up to 50 mm waste and vent pipes	Solvent cement and push-fit ring seal
Unplasticized PVC	Over 50 mm soil and vent stacks; vent pipes under 50 mm	Solvent cement and push-fit ring seal
Pitch fibre	Over 50 mm discharge and vent stacks	Driven taper or polypropylene fitting with a push-fit ring seal

#### ▪ Maintenance

Periodic inspection, testing, trap clearance, removal of rust and repainting should be a feature of an overall service maintenance schedule. Washers on access covers require occasional replacement. The use of chemical descaling

agents, hand or machine operated rodding and high-pressure blockage removal must be carefully related to the drainage materials and the skill of the operator.

- **Lime scale removal**


Lime scale is found in hard-water areas. A dilute corrosion-inhibited acid-based descaling fluid is applied directly to scale visible on sanitary appliances and is then thoroughly flushed with clean water. The fluid is a mixture of 15% inhibited hydrochloric acid and 20% orthophosphoric acid.

- **Removal of grease and soap residues**

A strong solution of 1 kg of soda crystals and 9 l of hot water is flushed through the system. The soda crystals are mixed with the hot water in a basin. When the soda is fully dissolved, the plug is released. This may be necessary frequently in commercially used appliances.

- **Blockage**

A hand plunger may be sufficient but repeated blockage should be investigated. Hand rodding from the nearest access point can be performed using various tools as appropriate. A kinetic ram gun can be used for blockage in branch pipes. The impact of compressed air from the gun creates a shock wave in the water, which dislodges the solids. However, a blow-back from a stubborn blockage may injure the operator and damage the pipework and therefore the ram gun must be limited to the removal of soft materials.



Soil and vent stack in housing.



## Air static pressure distribution in soil and vent pipes.

### Q. Electrical distribution within a building:


- d) Electrical services –
  - i) requirements in high rise buildings
  - ii) Layout of wiring - types of wiring
  - iii) Fuses and their types
  - iv) Earthing and their uses

The safe and economical use of electricity is of paramount importance to the building user and the world as it is the most highly refined form of energy available. Electricity production consumes up to three times its own energy value in fossil fuel, and electricity in its distributed form is potentially lethal.


In this chapter the handling methods and safety precautions for utilizing electricity are explained and a range of calculations, which can easily be performed by the services designer or constructor prior to employing specialist help, is introduced.

### Electrical distribution within a building:

The incoming cable, residual current device and meter are the property of the electricity supply authority. Underground cables are at a depth of 760 mm under roads, and enter the building through a large radius service duct of 100 mm internal diameter. A drainpipe can be used for this purpose, laid through the foundations and rising directly to the meter compartment. External meter compartments can be used. The meter should not be exposed to damp or hot conditions and the electricity supply authority's advice should be sought. Figure 13.6 shows a distribution system for a dwelling.




## EARTHING SYSTEMS



## Cold Water Distribution in high rise building lay out of installation

- **Direct Cold Water Systems** ~ the cold water is supplied to the outlets at mains pressure the only storage requirements is a small capacity cistern to feed the hot water storage tank. These systems are suitable for districts which have high level reservoirs with a good supply and pressure. The main advantage is that drinking water is available from all cold water outlets
- For efficient operation, a high pressure water supply is essential particularly at periods of peak demand. Pipe work is minimal and the storage cistern supplying the hot water cylinder need only have 115 litres capacity. The cistern may be located within the airing cupboard or be combined with the hot water cylinder. Drinking water is available at every draw-off point and maintenance

valves should be fitted to isolate each section of pipe work. With every outlet supplied from the main, the possibility of back siphonage must be considered. Back siphonage can occur when there is a high demand on the main. Negative pressure can then draw water back into the main from a submerged inlet, e.g. a rubber tube attached to a tap or a shower fitting without a check valve facility left lying in dirty bath water.



## HOT WATER SUPPLY SYSTEMS

### • Direct System of Hot Water Supply

The hot water from the boiler mixes directly with the water in the cylinder. If used in a soft water area the boiler must be rust proofed. This system is not suited to hard waters, typical of those extracted from boreholes into chalk or limestone strata. When heated the calcium precipitates to line the boiler and primary pipe work, eventually 'furring up' the system to render it ineffective and dangerous. The storage cylinder and associated pipe work should be well insulated to reduce energy losses. If a towel rail is fitted, this may be supplied from the primary flow and return pipes.

### • Indirect System of Hot Water Supply

This system is used in 'hard' water areas to prevent scaling or 'furring' of the boiler and primary pipe work. Unlike the direct system, water in the boiler and primary circuit is not drawn off through the taps. The same water circulates continuously



Room/building/accommodation	Air changes per hour
Assembly/entrance halls	3-6
Bathrooms (public)	6*
Boiler plant rooms	10-30 <sup>†</sup>
Canteens	8-12
Cinema/theatre	6-10
Classrooms	3-4
Dance halls	10-12
Dining hall/restaurants	10-15
Domestic habitable rooms	approx. 1*
Factories/garages/industrial units	6-10

## Types of Ventilation

1. **Natural ventilation**
2. **Artificial/ Mechanical ventilation**

### 1. Natural ventilation



Ventilation provided by various natural means is called natural ventilation. Natural ventilation is an economic means of providing air changes in a building.

The sources for natural ventilation are

- wind effect/pressure and
- Stack effect/pressure.
- Passive Stack Ventilation (PSV)


- **Stack effect:**

Stack Effect is an application of convected air currents. Cool air is encouraged to enter a building at low level. Here it is warmed by the occupancy, lighting, machinery and/or purposely located heat emitters. A column of warm air rises within the building to discharge through vents at high level.



- **Passive Stack Ventilation (PSV)**

- PSV consists of vertical or near vertical ducts of 100 to 150 mm diameter, extending from grilles set at ceiling level to terminals above the ridge of a roof. Systems can be applied to kitchens, bathrooms, utility rooms and sometimes sanitary accommodation.
- PSV is energy efficient and environmentally friendly with no running costs. It works by combining stack effect with air movement and wind passing over the roof. It is self-regulating, responding to a temperature differential when internal and external temperatures vary.




## 2. Mechanical ventilation

Mechanical ventilation systems are frequently applied to commercial buildings, workshops, factories, etc., where the air change requirements are defined for health and welfare provision.

- Mechanically Assisted Ventilation Systems (MAVS)
- Mechanical Ventilation with Heat Recovery (MVHR)
- Fan assisted ventilation systems

### • Mechanically Assisted Ventilation Systems (MAVS)

- MAVS may be applied to dwellings and commercial premises where PSV is considered inadequate or impractical.
- This may be because the number of individual ducts would be excessive, i.e. too space consuming and obtrusive with several roof terminals.




- A low powered (40 W) silent running fan is normally located within the roof structure. It runs continuously and may be boosted by manual control when the level of cooking or bathing activity increases.
- Humidity sensors can also be used to automatically increase air flow.

### ► Mechanical Ventilation with Heat Recovery (MVHR)


- MVHR is a development of MAVS to include energy recovery from the warmth in fan extracted moist air from bathrooms and kitchens.
- The heat recovery unit contains an extract fan for the stale air and a fresh air supply fan and a heat exchanger. This provides a balanced continuous ventilation system, obviating the need for ventilation openings such as trickle ventilators.

- Apart from natural leakage through the building and air movement from people opening and closing external doors, the building is sealed to maximize energy efficiency. Up to 70% of the heat energy in stale air can be recovered



#### ► Fan assisted ventilation systems

- Fan assisted ventilation systems supplying external air to habitable rooms must have a facility to pre-heat the air.
- They must also have control over the amount of air extracted; otherwise there will be excessive heat loss.



#### Types of Fan

- **Propeller fan** - does not create much air pressure and has limited effect in ductwork. Ideal for use at air openings in windows and walls.

- **Axial flow fan** - can develop high pressure and is used for moving air through long sections of ductwork. The fan is integral with the run of ducting and does not require a base.
- **Bifurcated axial flow fan** - used for moving hot gases, e.g. flue gases, and greasy air from commercial cooker hoods.
- **Cross-flow or tangential fan** - used in fan convactor units.
- **Centrifugal fan** - can produce high pressure and has the capacity for large volumes of air. Most suited to larger installations such as air conditioning systems. It may have one or two inlets. Various forms of impeller can be selected depending on the air condition. Variable impellers and pulley ratios from the detached drive motor make this the most versatile of fans.

### Lighting – Requirement of lighting, Measurement of light intensity

Lighting or illumination is the deliberate application of light to achieve some practical or visual effect. Lighting includes the use of both artificial light sources such as lamps and light fixtures, as well as natural illumination by capturing daylight.

Indoor lighting is usually accomplished using light fixtures.

**Lighting has the following requirements:**

- For visibility
- For comfort
- For daily habitable purposes
- For a refreshing environment
- For growth of life and intelligence

**Types of lighting/ illumination:**

1. Natural illumination
2. artificial illumination

#### 1. Natural illumination

Natural illumination is primarily due to SUN during daytime. So Day lighting is often used as the main source of light during daytime in buildings.

- Natural illumination by penetration of direct solar and diffuse sky visible radiation requires correctly designed passive architecture.
- Large glazed areas may provide sufficient day lighting at some distance into the building, Using windows, skylights, or light shelves.
- Reflected illumination from other buildings, particularly from those having reflective glazing or metallic architectural features, may cause annoyance.
- Higher day lighting can also cause glare, overheating and high heating and cooling energy costs.

#### 2. artificial illumination

Artificial lighting is provided to supplement daylight on a temporary or permanent basis. Artificial lighting is the illumination by the help of light bulbs, lamps and several other electrical lighting systems.

- Artificial light sources such as lamps and light fixtures are necessary during dark areas of buildings both in day and night time.
- Local control of lights by manual and/or automatic switches aids economy in electricity consumption.



## Measurement of light intensity

### Illumination intensity/ illuminance:

- ❖ It is a measure of the intensity of the incident light
- ❖ illuminance, measured in **lux** i.e. **lumen/m<sup>2</sup> (1 lux = 1 lumen / sq meter)** a measure of the intensity, as perceived by the human eye, of light that hits or passes through a surface.
- ❖ Light Level or illuminance, is **the total luminous flux incident on a surface, per unit area**. The work plane is where the most important tasks in the room or space are performed.
  - The outdoor light level is approximately 10,000 lux on a clear day.
  - In the building, in the area closest to windows, the light level may be reduced to approximately 1,000 lux.
  - In the middle area its may be as low as 25 - 50 lux. Additional lighting equipment is often necessary to compensate the low levels.
  - Earlier it was common with light levels in the range 100 - 300 lux for normal activities.
  - For precision and detailed works, the light level may even approach 1500 - 2000 lux.

The table below is guidance for recommended light level in different work spaces

Activity	Illumination (lux, lumen/m <sup>2</sup> )
Family living room	50 lux
Hallway/toilet in office buildings	80 lux
Homes, Theaters, Archives	150
Easy Office Work, Classes	250-300
Show Rooms, Laboratories	500
Detailed Drawing Work, Very Detailed Mechanical Works	1500-2000

## QUESTIONS AND ANSWERS

### 1. write four properties of fresh concrete

- a. Setting
- b. Workability
- c. Bleeding and Segregation
- d. Hydration

### 2. write four properties of hardened concrete

- a. Strength
- b. Durability
- c. Creep
- d. Shrinkage
- e. Elasticity
- f. Permeability

### 3. What is an escalator?

**Escalator** is a moving staircase – a conveyor transport device for carrying people between floors of a building

### 4. Define plinth band

#### ***Plinth Band***

Plinth band is a band provided at plinth level of walls on top of the foundation wall. This is to be provided where strip footings of masonry are used and the soil is either soft or uneven in its properties as frequently happens in hill tracts.

### 5. What is a dragline?

It is an excavating equipment, used to excavate earth and loading earth into hauling units, also deposit the excavated earth in embankments or spoil banks.

### 6. Define Owning and operating cost

The cost of ownership of equipment to which the fuel cost is added for running the equipment

### 7. What is curing of concrete?

Curing is the process of controlling the rate and extent of moisture loss from concrete during cement hydration

**8. Write ratios for M15, M20.**

M15 - 1:2:4, M20 – 1: 1½:3

**9. Write two methods of curing.**

- a. Ponding
- b. Wet covering

**10. Write and define the unit of illumination.**

lux i.e. lumen/m<sup>2</sup> is unit to measure illumination and is defined as is the total luminous flux incident on a surface, per unit area

**11. Define workability of concrete.**

*Workability* is the ability of a fresh concrete mix with which the concrete can mix, transport, place and compacted is called the workability of concrete

**12. Define creep of concrete.**

**Creep** is the tendency of concrete structures to move slowly or deform permanently under the influence of stresses.

**13. What are the Factors affecting workability**

- a. Water content in the concrete mix
- b. Amount of cement & its Properties
- c. Aggregate Grading (Size Distribution)
- d. Nature of Aggregate Particles (Shape, Surface Texture, Porosity etc.)

**14. How To improve the workability of concrete**

- a. increase water/cement ratio
- b. increase size of aggregate
- c. increase the mixing time
- d. with addition of air-entraining mixture

**15. Write four Methods of proportioning concrete mix.**

- a. ACI Mix design method
- b. DOE Mix design method
- c. RLL Mix design method
- d. Minimum void method

**16. What are plan configuration problems**

- a. symmetry
- b. Regularity
- c. Separation of Blocks
- d. simplicity

**17. What is Retrofitting of Structures?**

Retrofitting is the modification of existing structures to make them more resistant to seismic activity, ground motion, or soil failure due to earthquakes.

**18. What are the compacting equipments?**

- a. tamping rollers
- b. Smooth wheel rollers,
- c. Pneumatic tired rollers and
- d. vibrating compactors

**19. What are the earth moving equipments**

- a. drag line,
- b. tractor,
- c. bulldozer,
- d. Power shovel

**20. What is batching of concrete?**

**Ans:** Batching is the process of weighing or volumetrically measuring each ingredients (cement , sand , coarse aggregate, water and admixture) and placing the ingredients into a mixer for a batch of concrete to produce a uniform quality concrete mix.

**21. Write the types of drum type mixers.**

**Ans:** 1. Tilting 2. Non-Tilting 3. Reversing or Forced Action

**22. What is hydration of cement?**

**Ans:** The reaction of cement with water is termed "hydration". This involves many different reactions, often occurring at the same time. As the reactions proceed, the products of the hydration process gradually bond together the individual sand and gravel particles, and other components, to form a solid mass.

**23. Write two methods of measuring workability of concrete.**

**Ans:** Slump cone test, Compacting factor test

**24. Define segregation and bleeding of concrete.**

**Segregation** can be defined as the separation of the constituent materials of concrete

**Bleeding** in concrete is sometimes referred as water gain. It is a particular form of segregation, in which some of the water from the concrete comes out to the surface of the concrete

**25. define W/C ratio of concrete**

The **water-cement ratio** is the ratio of the weight of water to the weight of cement used in a concrete mix and has an important influence on the quality of concrete produced. A lower water-cement ratio leads to higher strength and durability

**26. What are the types of elevator?**

- a. electric traction type
- b. hydraulic type

### **27. What is Stack effect?**

- Stack effect is the phenomenon in a building or building component caused by wind pressure and temperature differentials which results in air being drawn through some components of a building and out others creating a continuous pattern of air flow.
- During the heating season, the warmer indoor air rises up through the building and escapes at the top either through open windows, ventilation openings, or other forms of leakage. The rising warm air reduces the pressure in the base of the building, drawing cold air in through either open doors, windows, or other openings and leakage. During the cooling season, the stack effect is reversed

### **28. What are Ceiling Band and Gable Band?**

#### ***Ceiling Band***

It is a band provided immediately below the roof or floors.

#### ***Gable Band***

It is a band provided at the top of gable masonry below the purlins.

### **29. What is earthquake?**

An earthquake is the vibration of the earth's surface that follows a sudden release of energy in the crust. During an earthquake, the ground surface moves in all directions

### **30. Why Ventilation is required?**

- a. Provide fresh air for respiration
- b. Preserve the correct level of oxygen in the air
- c. Control carbon dioxide content to no more than 0.1%
- d. Control moisture

### **31. What are the types of hot water supply systems**

- a. Direct System of Hot Water Supply
- b. Indirect System of Hot Water Supply

### **32. What is curing requirements of Concrete**

Curing is necessary to provide continuously wetting the exposed surface thereby preventing the loss of moisture from it. Ponding or spraying the surface with water are methods typically employed to this end.

### **33. What is design mix concrete?**

It is a process of selecting suitable ingredients and determining their relative proportions with the objective of producing concrete of having certain minimum workability, strength and durability as economically as possible.

### **34. What are the data required for mix design?**

- a. Characteristic compressive strength
- b. Degree of workability
- c. Type and maximum size of aggregate to be used and
- d. Standard deviation (s) of compressive strength of concrete.

**35. define bulldozer**

It is an excavating equipment for short haul applications upto 100m, and is a versatile equipment.

**36. What are the factors affecting owning and operating cost of equipment?**

- a. initial cost
- b. service condition
- c. no. of hours it is to be used per year
- d. Useful life etc.

**37. What are the costs included in owning and operating?**

- a. depreciation cost
- b. maintenance and repair cost
- c. investment cost
- d. fuel cost
- e. lubricating oil cost

**38. What are the advantages of mix design?**

- a. Better strength
- b. Better imperviousness and durability
- c. Dense and homogeneous concrete
- d. Economical

**39. What are the Requirements of Lighting?**

- a. For visibility
- b. For comfort
- c. For daily habitable purposes
- d. For a refreshing environment
- e. For growth of life and intelligence

**40. What are the systems of Mechanical ventilation?**

- a. Mechanically Assisted Ventilation Systems (MAVS)
- b. Mechanical Ventilation with Heat Recovery (MVHR)
- c. Fan assisted ventilation systems

## PREFABRICATION

- Prefabrication is the practice of assembling components of a structure in a factory or other manufacturing site, and transporting complete assemblies or subassemblies to the construction site where the structure is to be located.
- Prefabrication is one of the architectural constructions. Large units of a building are produced in factories to be assembled, ready-made, on the building site.
- This technique permits the speedy erection of very large structures. Units may include doors, stairs, windows, wall panels, floor panels, roof trusses and even entire buildings. Prefabricated building:
- Prefabricated building is a type of building that consists of several factory-built components or units that are assembled on-site to complete the unit. The term 'prefabricated' is buildings built in components (e.g. panels), modules (modular homes), transportable sections (manufactured homes), It may also be used to refer to mobile homes.
- Different Between Prefabricated Constructions and Conventional Type: The conventional method of building a house is to transport bricks, timber, cement, sand, and construction aggregate, etc to the site, and to construct the house on site from these materials.
- In prefabricated construction, only the foundations and floor slabs are constructed in this way, while sections of walls and roof are prefabricated

### Need for Prefabrication:

1. Cost of construction
2. shorter construction time & easy of expansion
3. utilization of material
4. attractive finishes
5. highly efficient for weather resistance
6. single source assurance
7. insurance advantage
8. Material Properties In of Prefabricated Structures Quick to assemble & Cost-effective
9. Portable/movable
10. Strong
11. Waterproof, Moisture proof
12. Fire Resistant

### Prefabrication Types:

1. Conventional prefabrication construction is the most traditional construction method where all the construction activities are in-situ practices on site:
2. Semi-prefabrication divides as two sub-categories: system formwork and nonstructural semi-prefabrication, involving a part of in-situ construction activities and a part of prefabrication. Normally, the non-structural semi-prefabrication is applied on façade, curtain walls, lost form systems and dry wall systems;
3. Comprehensive prefabrication involves a structural part and pre-finished construction. Examples of applications of structural comprehensive prefabrication include staircases, slabs, columns and beams: and
4. Volumetric off-site fabrication encloses usable space but does not constitute the whole building. Volumetric off-site fabrication is mainly used for 'facilities' and includes solutions on office washrooms, plant rooms, building services risers and lifts.

#### **ADVANTAGES OF PREFABRICATION**

1. Self-supporting ready-made components are used, so the need for formwork, shuttering and scaffolding is greatly reduced.
2. Construction time is reduced and buildings are completed sooner, allowing an earlier return of the capital invested.
3. Quality control can be easier in a factory assembly line setting than a construction site setting.
4. Prefabrication can be located where skilled labour is more readily available and costs of labour, power, materials, space and overheads are lower.
5. Time spent in bad weather or hazardous environments at the construction site is minimized.
6. Less waste may be generated and in a factory setting it may be easier to recycle it back into the manufacturing process, for instance it is less costly to recycle scrap metal generated in a metal fabrication shop than on the construction site.
7. On-site construction and congestion is minimized.

#### **DISADVANTAGES OF PREFABRICATION**

1. Careful handling of prefabricated components such as concrete panels or steel and glass panels is required.
2. Attention has to be paid to the strength and corrosion-resistance of the joining of prefabricated sections to avoid failure of the joint.
3. Similarly, leaks can form at joints in prefabricated components.
4. Transportation costs may be higher for voluminous prefabricated sections than for the materials of which they are made, which can often be packed more compactly.



5. Large prefabricated sections require heavy-duty cranes and precision measurement and handling to place in position.

### **Modular coordination:**

Modular coordination or MC is a dimensional system. It is a dimension and space coordination concept in which building and components are placed at their designations based on the unit or basic module known as "1M" that equals to 100 mm. The use of MC is an important factor in IBS effective application as it completes the industry through quality control and increase of productivity.

### **QUESTIONS AND ANSWERS**

#### **1. Define prefabrication.**

The term prefab can apply to any construction method where the significant part of the construction takes place off site in a factory. That produces relatively large complex features that assembled at the site into the finished building.

#### **2. What is meant by modular Coordination?**

Modular coordination is a concept for coordinating dimension and space for which building and component are dimensionally it used and positioned in basic units (or) modules. The standard specify that the module basic  $M = 100 \text{ mm}$ . As the basic unit be used in a square of  $M$ .

#### **3. What are the characteristics of Modular concept.**

- I) The basic module is small in terms of add size in order to provide design flexibility, yet large enough to promote simplification in the component variation in sizes.
- II) Industry friendly features that not only for manufacturing but also the transportation and assembly requirements.
- III) Internationally accepted to support international market.

#### **4. Write out the advantages & disadvantages of prefabrication ?**

- I) Self supporting readymade components are used, so the need for formwork, shuttering and scaffolding is greatly reduced.
- II) On-site construction and condition is minimized.
- III) Less waste may occur.

#### **Disadvantages :**

- I) Careful handling of prefabricated components such as concrete panels (or) steel and glass Panels is reduced.
- II) Similarly leaks can form at joints in prefabricated component.

#### **5) Define the term Off-site fabrication.**

Off-site fabrication is the process that incorporates prefabrication and preassemble the process involves the design and manufacture of units usually remote from the work site and the installation at the site to form the permanent work at the site.

#### **6) Write short note on Production process.**

The production of concrete blocks consists of four basic process They are,  
1) Mixing 2) Moulding 3) Curing 4) Cubing

7) List out the limitations of prefabrication .

I) Extra reinforcement is required to take care of handling and erection stresses .

II) Temporary props may be required in some cases ,before the on-site concrete joints achieve strength .

III) The cracks may develop at the joints between the precast in –site concrete due to shrinkage and temperature stresses . To overcome them extra steel is required across joint.

8) What are all the Prefab materials ?

- Structural insulated panels (SIPs).
- Insulating concrete forms (ICFS).
- Prefab foundation system .
- Steel framing .
- Concrete framing .
- Large - modular system

9) Insulating concrete forms :

Insulating concrete forms (ICE) are a prefab construction material consisting of hollow EPS foam blocks that are stacked and glued together on-site , creating the form that is filled with reinforcing bars and concrete.

10) Write short note on Principles of MC Concept ?

The principle objective of implanting MC is to improve productivity through the reduction of wastages in the production ,installation process , to improve quality in the construction industry and to encourage an open system .

## PART B

### 1.Explain Modular Coordination in detail

Modular coordination means the interdependent arrangement of a dimension based on a primary value accepted as a module. The strict observance of rules of modular coordination facilitated,

1. Assembly of single components into large components.
2. Fewest possible different types of component.
3. Minimum wastage of cutting needed.

**Modular coordination** is the basis for a standardization of a mass production of Component.

A set of rules would be adequate for meeting the requirements of conventional and prefabricated construction. These rules are adaptable for,

a. The planning grid in both directions of the horizontal plan shall be

1. 3M for residential and institutional buildings,
2. For industrial buildings,  
15M for spans up to 12m  
30M for spans between 12m and 18m  
60M for spans over 18m

The centre lines of load bearing walls shall coincide with the grid lines

b. In case of external walls the grid lines shall coincide with the centre line of the wall or a line on the wall 5 cm from the internal face of the wall

c. The planning module in the vertical direction shall be 1M up to and including a height of 2.8M.

d. Preferred increments for the still heights, doors, windows and other fenestration shall be 1M.

e. In case of internal columns the grid lines shall coincide with the centre lines of columns. In case of external columns, the grid lines shall coincide with the centre lines of the columns in the storey or a line in the column from the internal face of the column in the topmost storey.

KIIT \_ Abhijeet Prasad Dash

# CONSTRUCTION EQUIPMENTS



## **FACTORS AFFECTING SELECTION OF CONSTRUCTION EQUIPMENT**

- ❖ **USE OF EQUIPMENT AVAILABLE WITH THE ORGANIZATION**
- ❖ **SUITABILITY FOR JOB CONDITION WITH SPECIAL REFERENCE TO CLIMATIC AND OPERATING CONDITIONS**
- ❖ **UNIFORMITY OF TYPE**
- ❖ **SIZE OF EQUIPMENT**
- ❖ **USE OF STANDARD EQUIPMENT**
- ❖ **COUNTRY OF ORIGIN**
- ❖ **UNIT COST OF PRODUCTION**
- ❖ **AVAILABILITY OF SPARE PARTS AND SELECTION OF MANUFACTURERS**
- ❖ **SUITABILITY OF LOCAL LABOUR FOR OPERATION**

## **TYPES OF EARTH EXCAVATION EQUIPMENTS**

- 1. POWER SHOVEL**
- 2. BACK HOE**
- 3. DRAG LINE**
- 4. CLAM SHELL**

## POWER SHOVEL

- LONG-LASTING.
- EXCAVATE ALL TYPES OF EARTH EXCEPT HARD ROCK

### TYPES:

- WHEEL MOUNTED (HIGH SPEED - FIRM GROUND)
- CRAWLER MOUNTED (LOW SPEED - UNSTABLE SOIL)

### BASIC PARTS:

- |                     |                                                             |
|---------------------|-------------------------------------------------------------|
| * TRACK SYSTEM      | * CABIN                                                     |
| * CABLES            | * RACK & STICK                                              |
| * BOOM FOOT PIN     | * SADDLE BLOCK                                              |
| * BOOM POINT SHEAVE | * BUCKET ( Size = .375 m <sup>3</sup> to 5 m <sup>3</sup> ) |

## POWER SHOVEL

### OPERATION:

CABLE CONTROLLED & IT MAKES *OUTWARD STROKES* WHILE DIGGING.

### APPLICATIONS:


- CLOSE RANGE OF WORK.
- VERY HARD MATERIALS, BIG SIZED BOULDERS.
- DIGGING IN GRAVEL BANKS, CLAY PITS, CUTS IN ROAD WORKS, ROAD SIDE BERMS Etc.,

### FACTORS CONTROLLING OUTPUT:

- |                         |                     |
|-------------------------|---------------------|
| * CLASS OF MATERIAL     | * DEPTH OF CUTTING  |
| * ANGLE OF SWING        | * SKILL OF OPERATOR |
| * SIZE OF HAULING UNITS | * JOB CONDITION     |



## POWER SHOVEL



## DRAG LINE

- The drag line is so name because of its prominent operation of dragging the bucket against the material to be dug.
- Unlike the shovel, it has a long light crane boom and the bucket is loosely attached to the boom through cables.
- Because of this construction, a dragline can dig and dump over larger distances than a shovel can do.
- Drag lines are useful for digging below its track level and handling softer materials.

## DRAG LINE

### BASIC PARTS:


- |              |               |
|--------------|---------------|
| * BOOM       | * HOIST CABLE |
| * DRAG CABLE | * HOIST CHAIN |
| * DRAG CHAIN | * BUCKET      |

### APPLICATIONS:

- Dragging softer material and below its track level
- It is very useful for excavating trenches when the sides are permitted to establish their angle of repose without shoring.
- It has long reaches.
- Excavation for canals and depositing on the embankment without hauling units.



# LAYOUT OF DRAGLINE MACHINE



## DRAG LINE

### FACTORS CONTROLLING OUTPUT:

- TYPE OF MATERIAL
- DEPTH OF CUTTING
- SIZE AND TYPE OF BUCKETS
- SKILL OF OPERATOR
- SIZE OF HAULING UNITS & METHOD
- ANGLE OF SWING
- LENGTH OF CRANE BOOM
- JOB CONDITION

# BULL DOZERS

- **VERSATILE EQUIPMENT- ESSENTIALLY A HEAVY STEEL BLADE MOUNTED ON THE FRONT OF TRACTOR.**

## **CLASSIFICATION BASED ON:**

### **POSITION OF BLADES**

- **PERPENDICULAR BLADES**
- **BLADES AT AN ANGLE**

### **MOUNTING**

- **WHEEL MOUNTED**
- **CRAWLER MOUNTED**

### **CONTROL**

- **CABLE CONTROL**
- **HYDRAULIC CONTROL**



### **CONSTRUCTION:**

- ❖ **CONSIST OF HEAVY BLADE WITH CONCAVE PROFILE.**
- ❖ **BLADE IS ATTACHED TO THE BODY WITH TWO ARMS, A SUPPORTING FRAME & HELD BY TWO PUSH ARMS**


### **APPLICATION:**

- ❖ **SPREADING EARTH FILL**
- ❖ **CLEARING, OPENING UP PILOT ROADS**
- ❖ **BACK FILLING TRENCHES**
- ❖ **CLEARING CONSTRUCTION SITES**

KIIT \_ Abhijeet Prasad Dash

# Types of bulldozer blade

## Dozer Blades



**Figure 4-7** Common types of dozer blades.



# TRACTORS

❑ MULTI PURPOSE MACHINES MAINLY USED FOR PULLING AND PUSHING OTHER MACHINES FOR AGRICULTURAL PURPOSES.

## TYPES:

1. WHEEL TYPE ( <50 km/Hr )
2. CRAWLER TYPE ( <12 km/Hr )

## APPLICATIONS:

- ❖ CLEARING & EXCAVATING MACHINERY
- ❖ HAULING & CONVEYING MACHINERY

KIIT \_Abhijeet Prasad Dash

## **CRAWLER TRACTOR**



## **WHEEL TRACTOR**





## **COMPARISON BETWEEN CRAWLER AND WHEELED TRACTORS**

<b>CRAWLER TYPE</b>	<b>WHEELED TYPE</b>
1. Slow speed	1. Greater speed
2. More compact and powerful and can handle heavier jobs	2. Can handle only lighter jobs
3. Costly	3. Cheaper
4. Cost of operation and maintenance is high	4. Operational and maintenance cost is less
5. Stick control for steering	5. Wheel steering control
6. Moves on rough roads only	6. Moves on rough as well as good roads
7. Used for short distances	7. Used for longer distances
8. Requires skillful operation, maintenance and repairs	8. Lesser skills required for operations, maintenance and repairs

## **EARTH COMPACTION EQUIPMENTS**

- 1. SMOOTH – WHEEL ROLLERS**
- 2. SHEEP – FOOT ROLLERS**
- 3. PNEUMATIC TYRED ROLLERS**

## **SMOOTH – WHEEL ROLLERS:**

- **PLAIN STEEL ROLLERS**
- **SELF – PROPELLED (5 TO 25 TONNES)**
- **NO DEEP COMPACTION**
- **REAR WHEELS ARE LARGER IN DIAMETER AND THE FRONT ONES ARE WIDER**
- **DIESEL ENGINE TYPE**
- **COMPACTION IS BY STATIC WEIGHT OF ROLLER**

### **SUITABILITY:**

- **GRANULAR SOILS**
- **SAND**
- **GRAVEL**
- **CRUSHED STONES**

KIIT – Abhijeet Prasad Dash



## SMOOTH WHEEL ROLLER



# **SHEEP – FOOT ROLLERS**

- ☐ **HOLLOW STEEL DRUM WITH PROJECTED FEET MOUNTED AT 100 TO 200 MMC/C**
- ☐ **WEIGHT - 15 TONNES**
- ☐ **SPEED - 25 KM/HR**
- ☐ **COMPACTION IS BY KNEADING ACTION**
- ☐ **IN CONVERTIBLE ROLLERS THE FOOT PLATE CAN BE REMOVED**
- ☐ **IN TURN FOOT ROLLERS THE INDIVIDUAL SHEEP FOOT CAN BE CHANGED**

## **SUITABILITY:**

**CLAY, PREDOMINANTLY COHESIVE AND IMPERVIOUS SOIL**

# **SHEEP – FOOT ROLLERS**



# **PNEUMATIC TYRED ROLLERS**

- ✓ **CONSISTS OF A BASE PLATFORM MOUNTED BETWEEN TWO AXLES**
- ✓ **TRACKS OF THE REAR WHEEL LIE IN BETWEEN THE TRACKS OF THE FRONT WHEEL**
- ✓ **COMPACTION IS BY CONTROLLING THE GROUND CONTACT PRESSURE**
- ✓ **WEIGHT OR WIDTH OF THE WHEEL CAN BE SUITABLY INCREASED**

## **SUITABILITY:**

**FINE GRAINED AND WELL GRADED SANDS**

## **PNEUMATIC TYRED ROLLER**





## **The Cost of Owning and Operating Construction Equipment:**

There are several methods of determining the probable cost of owning and operating construction equipment. No known method will give exact costs under all operating conditions. At best the estimate is only a close approximation of the cost. Kept records for equipment previously used should give information which may be used as a guide for the particular equipment it was used under the same conditions. Factors that affect the cost of owning and operating construction equipment include:

1. The cost of the equipment delivered to the owner.
2. The severity of the conditions under which the equipment is used.
3. The number of hours the equipment is used per year.
4. The number of years the equipment is used.
5. The care with which the owner maintains and repairs the equipment.
6. The demand for used equipment when it is sold, which will affect the salvage value.

When it is necessary to estimate the cost of owning and operating construction equipment prior to purchasing it, cost records, based on past performance generally will not be available, therefore the following costs should be considered:

1. Ownership Costs:
2. Depreciation cost.
3. Investment Cost.

## **Economical Life of Construction Equipment:**

The owner of construction equipment should be interested in obtaining the lowest possible cost per unit of production. In order to accomplish this objective he must follow an informed program of equipment replacement. If the owner replaces it too soon, he will experience an unnecessary capital loss, whereas, if he waits too long, the equipment will have passed its period of economic operation. In order to determine the most economical time to replace equipment, accurate records of maintenance and repair costs and downtime must be kept for each machine.

The owner must consider all costs related to the ownership and operation of the equipment, and the effect which continued use will have on these costs. The costs to be considered are:

1. Depreciation and replacement.
2. Investment.
3. Maintenance and repairs
4. Downtime.
5. Obsolescence.

An analysis of the effect which hours of usage will have on each of these costs will establish the time at which a machine should be replaced.

### **Sources of Construction Equipment:**

Contractors and other users of construction equipment are concerned with a decision as to whether to purchase or rent equipment. Under certain conditions it is financially advantageous to purchase, whereas under other conditions it is more economical and satisfactory to rent it. There are at least three methods under which a contractor may secure the use of construction equipment:

1. Purchase the equipment.
2. Rent the equipment.
3. Rent the equipment with an option to purchase it at a later date.

The method selected should be the one that will provide the use of the equipment at the lowest total cost. Each of the three methods has both advantages and disadvantages which should be considered prior to making a decision. If the cost was the only factor to be considered, then an analysis of the cost under each method should give the answer. If other factors should be considered, they should be evaluated and applied to the cost as a basis on which to reach a decision. The correct decision for one contractor will not necessarily apply for another contractor.